PREMIER®

MANUAL DE INSTRUCCIONES
EXPRIMIDOR
ED-1197

ESTIMADO CLIENTE

Felicitaciones por su compra!
Por favor lea cuidadosamente este manual, y guárdelo para su futura referencia.
Si necesita soporte adicional, no dude en escribir a: ***info@premiermundo.com***

ATENCIÓN

Cuando use aparatos eléctricos, debe tomar en cuenta las siguientes precauciones.

1. Asegúrese que el requerimiento de energía del aparato corresponde con el voltaje de su red domiciliaria.
2. No presione el cono con mucha fuerza ni haga funcionar el aparato por más de 10 minutos consecutivos, para evitar que se recaliente. Si tiene que usar mucho tiempo el exprimidor, déjelo descansar de cuando en cuando.
3. No coloque el aparato cerca de fuentes de calor o cerca del agua hirviendo.
4. No sumerja el aparato en ningún líquido.
5. No deje que el cable de energía toque superficies calientes.
6. Desenchufe el aparato después de usarlo y antes de limpiarlo.
7. No sumerja el cable o el cuerpo del motor en ningún líquido.
8. No use el aparato si el cable está dañado o si no funciona correctamente. En esos casos, debe llevar el equipo al servicio técnico autorizado.
9. No se recomienda usar extensiones de corriente ya que puede causar daños o accidentes personales.
10. Si el cable de energía se daña, debe ser remplazado por el fabricante o por personal técnico calificado, con el fin de evitar cualquier daño.
11. Este aparato ha sido diseñada para ser usado en interiores y no debe ser usada para fines industriales.

INSTRUCCIONES DE USO

- Antes de enchufar el aparato al tomacorriente, asegúrese que el voltaje de su red doméstica corresponda con el requerimiento de energía del exprimidor que figura en la etiqueta adherida a la base del mismo.

- Parata por la mitad las naranjas que quiera exprimir. Tome una mitad y presiónela suavemente sobre el cono del exprimidor. El motor empezará a funcionar automáticamente para extraer el jugo dentro del recipiente. La pulpa y las semillas quedarán en el filtro.
  El motor está diseñado para girar en ambas direcciones, cambiando de sentido de tiempo en tiempo. Una vez extraído todo el jugo, quite la naranja para que el motor se detenga automáticamente.

- Cuando haya terminado de usar el extractor, desenchúfelo del tomacorriente, quite el cono y vierta el jugo.

LIMPIEZA Y MANTENIMIENTO

Desenchufe el aparato antes de limpiarlo. Puede lavar el recipiente y el cono en agua. No sumerja el cuerpo del aparato, el cable o el enchufe en ningún líquido.

DIAGRAMA DEL CIRCUITO



220VAC 50Hz 15W

PREMIER®

INSTRUCTION MANUAL

JUICER

ED-1197

DEAR CUSTOMER

Congratulations for your purchase!
Please read this manual carefully, and keep it for future reference.
If you need extra support, please write to ***info@premiermundo.com***

READ THESE INSTRUCTIONS CAREFULLY:

The following precautionary measures should be adopted when using electrical appliances:

1. Ensure that the voltage of the appliance corresponds to that of your power supply.
2. To avoid the appliance overheating, do not press down on the cone with excessive force or operate the appliance for more than ten minutes continuously. Take breaks from time to time during lengthy processing operations.
3. Do not place the appliance over or near sources of heat or in boiling water.
4. Do not immerse the body of the appliance in water or other liquids.
5. Do not allow the power cable to come in to contact with hot surfaces.
6. Always disconnect the plug from the power supply when the appliance is not in use, or before cleaning.
7. Never immerse the motor body, plug or power cable in water or other liquids. Use a damp cloth to clean them.
8. Do not use the appliance with a damaged cable or plug, or if it shows any sort of malfunction. Take the appliance to your nearest authorized Service Centre.
9. The use of extension cables not recommended by the manufacturer may cause damage or accidents.
10. If the power supply cable is damaged, it must be replaced by the Manufacturer or by a person with similar qualifications, in order to avoid any risks.
11. The appliance has been designed for DOMESIC USE ONLY and should not be used for commercial or industrial purposes.

INSTURCTIONS FOR USE

- Before connecting the appliance to the power supply, ensure that the supply voltage corresponds to that shown in the technical data label on the lower part of the appliance.
- Halve the orange to be juiced. Take one half of the orange and press it lightly on to the juicer cone. The motor will start automatically, straining the juice straight into the juice container, while the seeds and pulp are held in the filter. The motor is designed to rotate in both directions, automatically reversing form time to time. When all the juice has been extracted, release the pressure on the orange on the juicer cone and the motor will stop automatically.
- As soon as the juice is ready, disconnect the plug form the power supply, take out the juicer cone, and then pour the juice out.

CLEANING AND MAINTENANCE

Before cleaning the appliance, always disconnect the plug form the power supply. The juicer cone and juice container can be washed in water. Never immerse the appliance body, the power supply cable or plug in water or other liquids.

CIRCUIT DIAGRAM



220VAC 50Hz 15W